


Instruction Manual
MORSØ Digital Measuring System
Manual
Morsø-F



Haraldsvej 21 - DK-8960 Randers - Denmark
Tel.: +45 8643 5155 - Fax: +45 8643 5100
e-mail: danlist@danlist.dk
Home page: www.danlist.dk

Description	Paragraph	Page
Introduction		A-1
Fitting of the Measuring System		B-1 – B-1.1
Software S (Standard)		C-1
Keys' Function	1	C-1
Programming Mode	2	C-1.1
Parameter Description	3	C-1.2
Parameter Description	3	C-1.3
Input Mode	4	C-1.4
Input Mode	4	C-1.5
Trouble Shooting		C-2
Application Examples		C-3
Application Examples		C-3.1
Appendix: Parameter List		C-4

Introduction



We recommend that you read this instruction manual thoroughly before using this equipment.

Damage or faults on the equipment caused by misuse or incorrect operation are not covered under our conditions of warranty.

Use of the Instruction Manual:

The reference system of this Instruction Manual described below will help you to quickly find the information you require (Picture A-1-1)

(1) Subject Heading

(2) Page Index

The letter (A) refers to the description of the section.

The number (1) refers to the page number of that section.


(3) Text

Description of the subject heading.

Illustration



A three dimensional, numbered drawing of the text subject. The numbers in the text correspond to the numbers in the drawing.

Fitting




The beam is fitted onto the extension table by means of the screws in the same way as the standard beam is fitted.

Fitting



The digital display is pushed into the beam from the end – as shown on the pictures.





The stop beam is fitted into the stop block with the digital display.

General Description

SOFTWARE S (Standard)

1. Keys' function

Depending on the operating mode the keys may have additional functions (see 'Programming mode' and 'Input mode'). The keys are pressed singly or in pairs (together).



1. Programming
2. Select 'value'
3. Select 'digit'
4. Store value
5. Display: battery change / incremental measurement function / sign

2. Programming mode

The display is either pre-programmed to standard values at our works or, if the order defines customer-specific parameters, these will be pre-programmed at SIKO. Enter programming mode for parameter modification / programming. Normally programming is only necessary at initial installation. Parameters can be modified and checked at any time. They are stored in a non-volatile memory. Each parameter's designation, function and value range is shown in tables on the following pages.

To enter into programming mode:

Press key [**P**] for at least 4 s.

To leave programming mode:

Automatically, if no key has been pressed during approx. 30 s, or press key [**P**] until the end of the parameter list is reached.

To scroll parameter information:

Use key [**P**]

To change parameters:

Use keys [▲] and [◀]

To store modified parameters:

Press key [] then message "-sto-" will be briefly displayed.

3. Parameter description

At the end of this user information brochure you will find a detailed **parameter list** showing all programmable parameters and offering space for customer-specific programming values.

(in English, parameter Lan = "E")

Display "choice"	Designation / description
rES	Resolution: Determines the resolution of the display. Parameter "FrEE", allows the programming of a calculating factor.
FAc	Calculation factor (only available, if 'Resolution' has been programmed to "FrEE" before): Used to obtain for example an angle display. Basis is the maximal possible resolution of 1/100 mm. The calculation factor "FAc" which has to be programmed results from: $FAc = \text{meas. range} / \text{total travel distance [1/100 mm]}$ <i>Example:</i> Angle measurement on a circular disk with a display range of 0 ... 180°; display in 1/10°; circumference of the circular disk 942,48 mm; hence total travel distance 471,24 mm; $FAc = 1800 / 47124 = 0,3820$
dP	Decimal point (only available if 'Resolution' has been programmed to 'FrEE' before): Determination of the decimal point according to the resolution.
rEF	Reference value: Absolute reference point of the measuring system. This value is set by referencing the system according to chapter 4.
oFS	Offset: Can be any value; used to influence the value displayed, e.g. tool correction value.
dir	Counting direction of the measuring system: depends on the sensor's mounting position and can be changed subsequently.
"uP"	Upward
"dn"	Downward

Display "choice"	Designation / description
Auto "oFF" "on"	Switch-off method (Sleep-Mode): State of the automatic switch-off. no switch-off. automatically switch-off <i>Note: The display returns to the normal operation mode (display mode) by pressing a key or traversing the sensor.</i>
PEriod	Switch-off time: Interval between last measurement and automatic switching off.
4_Abs "oFF" "on"	Delayed reset function: Key [*] must be pressed for approx. 4 s to reset the display to reference value. Function off Function on
F_AbS "oFF" "on"	Access reset function: resetting to reference value via key [*] on front of the display. Reset function off Reset function on
F_rEL "oFF" "on"	Access incremental measurement: to switch from absolute dimension and zero-setting to subsequent relative dimension Increm. meas. function off Increm. meas. function on
F_rEE "oFF" "on"	Access reference value: to enter / change reference value Reference value function off Reference value function on
F_oFS "oFF" "on"	Access offset value: to enter / change offset value Offset value function off Offset value function on
Lan "d" "E"	Language: to choose the language in which the menu point are to be displayed. German English

4. Input Mode

Reset function via keyboard

- Press key [*] to set the display to the reference value.
- If parameter 'delayed reset function' (4_Abs) is programmed to "on", the display will be set to the reference value after approx. 4 s.

Preconditions: Parameter 'Reset enable' (F_AbS) in programming mode must be programmed to "on", but unit must **not** be left in programming mode (see chapter 2 'To leave programming mode').

Incremental measurement

Press the two arrow keys [▲] + [◀] simultaneously to activate incremental measurement function.

- The display is zeroed.
- The Display shows the symbol ◀◀
- Leave incremental measurement function by another simultaneous press of the two arrow keys [▲] + [◀]. The absolute measuring value is displayed again.
- While in the incremental measurement mode the display can also be set to zero by pressing key [*]. This does not change the absolute measurement in the background.

Precondition: Menu point 'Incremental measurement enable' (F_rEL) in programming mode must be programmed to "on", but unit must **not** be left in programming mode (see chapter 2 'To leave programming mode').

4. Input Mode

Reference and/or offset value modification

Press the two keys [P] + [▲] simultaneously to enter a new reference value.

Press the two keys [P] + [◀] simultaneously to enter a new offset value.

The display then shows the reference/offset value, which can be changed via the two arrow keys.

Press key [*] to store the new value.

In no key has been pressed for approx. 30 s or if you press again key [P], MA504 will return to display mode.

Precondition: In programming mode menu points 'Reference value input enable' (F_rEF) 'Offset input enable' (F_oFS) respectively must be programmed to "on", but unit must **not** be left in programming mode (see chapter 2 'To leave programming mode').

5. Trouble shooting

Error states are recognized and shown in the display:

Message: full

Description: display overrun

Action: check parameters and adjust them if necessary; set display to reference value.

Message: display blinking.

Description: missing referencing.

Action: set display to reference value

Message: S_Err

Description: faulty / no sensor signal

Action: check gap between sensor and magnetic strip.

Symbol: Battery symbol is active

Description: battery voltage below the admissible values.

Action: Change the batteries.

Message / Effect: ◀◀ comes on / MA504 cannot be referenced

Description: Display is still in incremental measurement function

Action: Leave incremental measurement function as described in chapter 4 or proceed as follows:

1. Enter into programming mode
2. Program parameter 'F_rEL' to "on"
3. Leave programming mode
4. Leave incremental measurement function as described in chapter 4
5. Enter programming mode again
6. Program parameter 'F_rEL' to "off"
7. Leave programming mode



Beware of the extremely sharp knives

6. Application Examples

Length measurement

Required: Display accuracy 1/10 mm. Display shall be zeroed via function key

Designation	Display	Progr. value
Resolution	rES	0.1
Decimal point	dP	0.0
Reference value	rEF	00000.0
Offset	oFS	00000.0
Counting direction	dir	uP
Switch-off method	Auto	oFF
Delayed reset function	4_Abs	oFF
Access: reset	F_AbS	on
Access: increm. meas.	F_rEL	oFF
Access: ref. value	F_rEF	oFF
Access: offset	F_oFS	oFF
Language	Lan	E

Angle measurement

Required: display range 0 ... 360°; display accuracy 1/10°. Display shall be zeroed via function key. Automatically switch-off after 0.5 h.

Conditions: circular disk with ø300 mm; resulting total circumference: $U = \pi \times 300 \text{ mm} = 942,48 \text{ mm}$

The programmable factor is calculated as follows:

FAC = total display range [1/10°] / circumference [1/100 mm]

$$3600 / 94248 = 0,03820$$

6. Application Examples

Designation	Display	Progr. value
Resolution	rES	FrEE
Calculating factor	FAc	0.03820
Decimal point	dP	0.0
Reference value	rEF	00000.0
Offset	oFS	00000.0
Counting direction	dir	uP
Switch-off method	Auto	on
Switch-off time	PEriod	0.5
Delayed reset function	4_Abs	oFF
Access: reset	F_AbS	on
Access: increm. meas.	F_rEL	oFF
Access: ref. value	F_rEF	oFF
Access: offset	F_oFS	oFF
Language	Lan	E

Appendix: Parameter list

Display	Designation / Value Range	Standard programm.	Your programming
rES	resolution (mm, In=inch) 1, 0.1, 0.05, 0.01, In 0.01, In 0.001, FrEE	0.1	
FAc	calculation factor (only if resolution has been programmed to "FrEE") 0.00001 ... 9.99999	1.00000	
dP	decimal point (only resolution has been programmed "FrEE") 0. to 0.000	0.00	
rEF	reference value: -99999 ... (+)99999	00000.0	
oFS	offset value: -99999 ... (+) 99999	00000.0	
dir	counting direction: uP, dn	uP	
Auto	switch-off method: on, oFF	oFF	
PEriod	switch-off time (in hours) (only for switch-off methods 'on') 0.2, 0.5;1.0	0.2	
4_Abs	Delayed reset function: on, oFF	oFF	
F_AbS	access reset function: on, oFF	on	
F_rEL	access increm. measurement: on, oFF	oFF	
F_rEF	access reference value: on, oFF	oFF	
F_oFS	access offset value: on, oFF	oFF	
LAn	language d, E	d	