

# **Burnishing Size**



## For Loose & Transfer Gold or Metal Leaf, including Aluminium

#### AFTER USING, WASH BRUSH OUT WITH WATER

Burnishing Size can be used as speedily as oil gilding with transfer leaf, but with the benefit of distressing & burnishing when required.

A further benefit is that leafing can commence within an hour of sizing, but

remain open for 2 - 3 days, without attracting dust particles in the way oil-size does (a common problem using oil size).

#### INSTRUCTIONS FOR USE

#### **Using Transfer Leaf**

Best results achieved by preparing surface with gesso, followed by 2 or 3 coats of acrylic paint/bole, all very highly smoothed.

Apply three coats of size 5 - 10 minutes between coats (time not critical) with a soft brush, allow to dry to slight tack (usually 10 - 20 minutes). Then ready to apply leaf & remains open for 2 - 3 days.

After testing, burnish with an agate and / or distressing (usually with pumice powder) can be started more or less immediately, or hours later to your convenience.

Finally, use the usual techniques for finishing, such as shellacs, wax etc.

### FOR WATER-GILDING TECHNIQUE (Using loose-leaf):-

As above, but dilute approx. 25% & after 2nd. coat apply third as with traditional waterliquor i.e. coat about 15 - 20 cms. at a time, then lay loose leaf, & finish as required.

N.B. If not using Gold or Aluminium leaf, always seal thoroughly to avoid tarnishing.



